


DIP SWITCH SETTING
(After changing the dip code, press "reset" or power-on again)

DIP S/W	Status	Function
PIN 1	ON	BMW 6.5 inch
PIN 2	ON	BMW 6.5 inch with special screen parameters
PIN 3	ON	BMW E60/E61 underpan
PIN 4	OFF/ON	Reversing gridline/Enable 360 panoramic
PIN 5	OFF/ON	NG/NG
PIN 6	OFF/ON	NG/NG
PIN 7	OFF/ON	NG/NG
PIN 8	OFF/ON	After market rear view CAM/Original rear view CAM



REMARK: Please stay in the AUX Interface when opening the CARPLAY Interface

- 1) Long press and hold "MENU" button to enter the Interface; long press and hold "MENU" button again, to exit.
- 2) iDrive knob to control up/down/right/left/ok.