



BMW (NBT) WIRING DIAGRAM ---- LDS-NBT-CP



DIP SWITCH SETTING

(After changing the dip code, press "reset" or power-on again)

PIN	Setting	Description
PIN1,3	OFF/ON	NG / BMW 10.25 inch splashscreen problems
PIN1	OFF/ON	BMW 10.2inch, 8.8inch/BMW6.5INCH&MINIshrink disply border
PIN2	OFF/ON	NG / BMW & MINI 6.5inch,8.8inch
PIN3	OFF/ON	NG / BMW ID4 headunit blank
PIN4	OFF/ON	Reversing gridline / Enable 360 panoramic
PIN5	OFF/ON	NG / NG
PIN6	OFF/ON	CVBS Rear view camera input / RGB video input
PIN7	OFF/ON	NG / NG
PIN8	OFF/ON	After market rear view camera / Original rear view camera



Remark:
Please keep in the original AUX interface when switch the Carplay interface

Long press and hold " BACK " button to switch MENU, long press again, exit the switch MENU;
Short press " MENU " button to open the " Siri " ;
iDrive knob to control up/down/right/left/ok.