

NTG4.5/4.7--DIP SWITCH SETTING

(After changing the dip code, press "reset" or power-on again)


| DIP S/W | Status | Description |
|---------|--------|---|
| PIN 1 | OFF/ON | 7inch (800*480) / 5.8 inch (480*234) |
| PIN 2 | OFF/ON | NG / NG |
| PIN 3 | OFF/ON | Close front camera / Open front camera |
| PIN 4 | OFF/ON | Reversing gridline/Enable 360 panoramic |
| PIN 5 | OFF/ON | NG / NG |
| PIN 6 | OFF/ON | Rear view camera CVBS input / RGB input |
| PIN 7 | OFF/ON | NG / NG |
| PIN 8 | OFF/ON | After market rear camera / Original rear camera |

NTG5.1/5.2/5.5--DIP SWITCH SETTING

(After changing the dip code, press "reset" or power-on again)

| DIP S/W | Status | Description |
|----------|--------|--|
| PIN 1, 2 | OFF/ON | 15~18 C class 7 inch / 15~17 S class 12.3 inch |
| PIN 2, 3 | OFF/ON | NG/15~17 S class 12.3 inch with other parameters |
| PIN 1 | ON | 15~18 year, all BENZ models with 8.4inch monitor |
| PIN 2 | ON | 15~18 A/B/E/CL/GLE class with 7 inch monitor |
| PIN 4 | OFF/ON | Reversing gridline/Enable 360 panoramic |
| PIN 5 | OFF/ON | NG / NG |
| PIN 6 | OFF/ON | Rear view camera CVBS input / RGB input |
| PIN 7 | OFF/ON | NG / NG |
| PIN 8 | OFF/ON | After market rear camera / Original rear camera |

REMARK: Please stay in the AUX Interface when opening the CARPLAY Interface



- 1) Long press and hold the "BACK" Button to enter the Interface, short press the "BACK" Button again to exit.
- 2) Short press the "C" or "★" Button to open "Siri".
- 3) Knob to control up/down/right/left/ok.