

ADP-36FV


MXN

*ADAPTER FOR UNIVERSAL USE OF SHUTTER CAMERA


NOTE!

The shutter from the camera will open automatically when the yellow trigger wire from the ADP-36FV is activated by DC10~32V

← **MONITOR**



• CONNECTION



• CONNECTOR PIN DESCRIPTION

Pin No.	Description
1	Audio
2	Heater & Shutter (DC 9V)
3	Power DC 12V
4	Video
5	Ground